

# Installation Tips

## ◆ Preparation (事前準備) ・Tools



## ◆ Overlap and/or Butt joint (重ね貼り / 突きつけの施工方法)

•Use a adhesive; starch and ethylene copolymer emulsion mixed.



•Apply adhesive evenly using with wide brush or roller.



- Fold or book without creasing to allow the moisture in backing.
- \*Do not take too long. It makes excessive shrinkage after dried.



- Start installing from the bottom.



- Adjust the line vertical and / or horizontal



- Smooth with soft and clean dried brush to remove the air.



- Straight the wrinkles by using smoother.



- Use trim guide or broad knife to cut straight.



- Press the edge if it comes off. (For corner bead, stile, rails, etc.)



- Same for the next sheet. (approximate 10mm is recommended for overlap.)



- Roll each seam lightly with a seam roller. Do not roll too hard. (Set the both edges perfectly for butt joint.)



- ◆ Double Cutting, overlap and trim joint - a technique used to obtain perfectly fitted seams. This is done by overlapping upper wallpaper over the other. Then a sharp blade is used to cut through both papers. The excessive edges are then. (相裁ちの施工方)

\* Wallpaper with backing ONLY. Do not install for Non-backing products in this method.

- Use plastic protective strip to protect the wall when cutting joints.



- Put plastic protective strip on the top of lower wallpaper backside.



- Put plastic protective strip on the bottom of upper wallpaper backside, where overlaps.



•Upper sheet comes over on lower sheet.



•Use trim guide or broad knife to cut the both wallpapers in straight.



•Peel away the waste on the upper wallpaper.



•Lift the overlap and peel away the waste on the lower wallpaper.



•Smooth lower wallpaper first.



•Smooth upper wallpaper. Then seam lightly with a seam roller. Do not to roll too hard.

